



KitchenAid®

Countertop Oven
Four de comptoir
Horno para mostrador
KCO124BM



PARTS AND FEATURES



- | | |
|---|--|
| 1 Toughened Glass Window | 11 Convection: Temperature Switch Mode |
| 2 Removable Crumb Tray | 12 Temperature/ Timer Knob |
| 3 Cool Down Surface for Removable Oven Rack | 13 Mode Knob: Cooking Mode Selector |
| 4 Chrome-plated Steel Broiling Rack | 14 Preheating Icon |
| 5 Enamel-coated Pan | 15 Shade Icon |
| 6 Chrome-plated Steel Oven Rack | 16 Shade Number Graphic |
| 7 Door Handle | 17 Convection Icon |
| 8 Air Fry Basket | 18 Fahrenheit Icon |
| 9 Start: Start Selected Cooking Mode | 19 Celsius Icon |
| 10 Cancel: Stops Selected Cooking Mode | 20 Hours Icon |
| | 21 Minutes Icon |
| | 22 Slices Icon |

NOTE: Press and hold the Convection button for 3 seconds to switch between the temperature units Fahrenheit (°F) and Celsius (°C).

PRODUCT SAFETY

Your safety and the safety of others are very important.

We have provided many important safety messages in this manual and on your appliance. Always read and obey all safety messages.



This is the safety alert symbol.

This symbol alerts you to potential hazards that can kill or hurt you and others.

All safety messages will follow the safety alert symbol and either the word “DANGER” or “WARNING.” These words mean:



You can be killed or seriously injured if you don't immediately follow instructions.



You can be killed or seriously injured if you don't follow instructions.

All safety messages will tell you what the potential hazard is, tell you how to reduce the chance of injury, and tell you what can happen if the instructions are not followed.

IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed, including the following:

1. Read all instructions. Misuse of appliance may result in personal injury.
2. Do not touch hot surfaces. Use handles or knobs.
3. To protect against risk of electrical shock, do not put cord, plugs, or any parts of the Countertop Oven in water or other liquid.
4. This appliance is not intended for use by children or by persons with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge. Close supervision is necessary when any appliance is used near children. Children should be supervised to ensure that they do not play with the appliance.
5. Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions, or is dropped or damaged in any manner. Return appliance to the nearest Authorized Service Facility for examination, repair, or adjustment.
6. The use of accessories/attachments not recommended or sold by KitchenAid may cause fire, electrical shock, or injury to persons.
7. Do not let cord hang over edge of table or counter, or touch hot surfaces.
8. Do not place on or near a hot gas or electric burner, or in a heated oven.
9. Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
10. Use extreme caution when removing Broiling Rack, Multipurpose Pan, Oven Rack, or disposing of hot grease.
11. Oversize foods or metal utensils must not be inserted in a Air Fryer as they may create a fire or risk of electric shock.
12. A fire may occur if Air Fryer is covered or touching flammable material, including curtains, draperies, walls and the like, when in operation. Do not store any item on top of the appliance when in operation.

PRODUCT SAFETY

- 13. Do not clean with metal scouring pads. Pieces can break off the pad and touch electrical parts, creating a risk of electric shock.
- 14. Extreme caution should be exercised when using containers constructed of materials other than metal or glass.
- 15. Do not store any materials, other than KitchenAid recommended accessories, in this Countertop Oven when not in use.
- 16. Do not place any of the following materials in the Air Fry: paper, cardboard, plastic, or anything similar.
- 17. Do not cover crumb drawer or any part of the Air Fry with metal foil. This will cause overheating of the oven.
- 18. To disconnect, turn the Countertop Oven off by pressing Cancel button, then remove plug from wall outlet.
- 19. Do not use the appliance outdoors.
- 20. Do not use the appliance for other than intended use.
- 21. Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.

SAVE THESE INSTRUCTIONS

This product is designed for household use only.



CAUTION: Hot surface.
(This alert symbol is required to comply with Mexican regulations.)

ELECTRICAL REQUIREMENTS

WARNING



Electrical Shock Hazard

Plug into a grounded 3 prong outlet.

Do not remove ground prong.

Do not use an adapter.

Do not use an extension cord.

Failure to follow these instructions can result in death, fire, or electrical shock.

Voltage: 120 V~
Frequency: 60 Hz
Power: 1800 W


NOTE: If the plug does not fit in the outlet, contact a qualified electrician.
Do not modify the plug in any way.
Do not use an adapter.

Do not use an extension cord. If the power supply cord is too short, have a qualified electrician or service technician to install an outlet near the appliance.


The cord should be arranged so that it will not drape over the countertop or tabletop where it can be pulled on by children or tripped over unintentionally.

GETTING STARTED

Before first use, clean all parts and accessories (see "Care and Cleaning" section). Place the Countertop Oven on a dry and flat level surface. Remove all packaging materials and labels, if present.



Make sure all sides are positioned with at least 4" (10 cm) distance.



Open the door and align the rack with the grooves for desired positions (see "Countertop Oven Rack Position" section).

⚠ WARNING



Electrical Shock Hazard


Plug into a grounded 3 prong outlet.

Do not remove ground prong.

Do not use an adapter.

Do not use an extension cord.

Failure to follow these instructions can result in death, fire, or electrical shock.



Plug into a grounded 3 prong outlet.
Your Countertop Oven is now ready to use.

NOTE: Upon first use, the Countertop Oven may produce light smoke. This is normal.

GETTING STARTED

TIME RECOMMENDATION - AIR FRY FUNCTION

FOOD	PORTION	TEMPERATURE	TIME
Chicken Nuggets	1 Layer	425°F (218°C)	8-10 minutes
Chicken Tenders	1 Layer	425°F (218°C)	13-15 minutes
Chicken Wings	1 Layer	425°F (218°C)	18-20 minutes
Fish Fillets	1 Layer	450°F (232°C)	12-14 minutes
Fish Sticks	1 Layer	450°F (232°C)	10-12 minutes
French Fries	1 Layer	425°F (218°C)	22-24 minutes
Mozarella Sticks	1 Layer	450°F (232°C)	5-7 minutes
Taquitos	1 Layer	400°F (204°C)	5-7 minutes

NOTE: Gently spray the basket with oil before each batch of food. No more oil is needed. Results may vary with different food brands and sizes. Follow Toaster Oven instructions from the back of the food package and reduce time.

TIP: When cooking fatty foods, such as non breaded poultry with skin, use the baking pan instead of the Air Fry Basket to catch excess oil that may drip from the food.

COOKING FUNCTIONS

PREHEATING

Preheating your Countertop Oven is important for consistent and even results. Once you select your desired cooking mode or any other settings, and press Start. The light ring around the Start button will be on, and the Preheat indicator will show on the LCD. Once the oven has reached the set temperature, a tone will sound to let you know that you can insert food and begin cooking. Preheating is NOT necessary in all cooking modes. To skip the Preheat and start the timer directly, push the Start button a second time.

NOTE: Automatic Preheat is not programmed for Dehydrate, Keep Warm, Reheat, Toast and Bagel functions.

CONVECTION

The convection fan is controlled by the Convection button. Pushing the Convection button will toggle the fan on or off for Bake, Broil, Keep Warm, and Reheat functions. A “Convection” label and fan icon will appear on the display when the convection fan is on. The Air Fry function uses a high speed convection fan that cannot be turned off. The Dehydrate function uses the high speed convection fan as preset, but it may be turned off by pushing the Convection button.

COOKING FUNCTIONS

COOKING FUNCTION	RACK NO.	PRESET TEMP. °F (°C)	TEMPERATURE RANGE °F (°C)	PRESET TIME	TIME RANGE	ELEMENTS RUN
Dehydrate	1 - 2	150°F (66°C)	80–180°F (27–82 °C)	6 hours	1 min–12 hours	2 bottom; high speed convect
Proof	1	90°F (32°C)	75–90°F (24–32°C)	30mins	1 min–1 hours	2 bottom
Air Fry	2	400°F (205°C)	150–450°F (66–232°C)	17mins	1 min–1 hours	2 top, 2 bottom, high speed convect
Bake	2	350°F (176°C)	150–450°F (66–232°C)	30mins	1 min–2 hours	2 top, 2 bottom, convect available
Broil	2	450°F (232°C)	350– 450°F (176°–232°C)	8mins	1 min–30 mins	2 top, convect available
Reheat	2	300°F (149°C)	150–450°F (66–232°C)	15mins	1 min–2 hours	2 top, 2 bottom, convect available
Keep Warm	2	170°F (77 °C)	150–450°F (66–232°C)	1 hour	1 min–2 hours	2 bottom, convect available

NOTE: Preheat can be skipped by pressing Start button twice - not recommended for Fresh Pizza function.

Cook all foods to minimum safe internal temperatures. Consuming raw or undercooked meats, poultry, seafood, shellfish, or eggs may increase your risk of food borne illness.

TOASTING FUNCTIONS	RACK NO.	PRESET SHADE	SHADE RANGE (Light to Dark)	PRESET SLICES	RANGE (# of slices)	ELEMENTS RUN
 Toast	2	4	1-8	2	1-6	Runs 4 elements
 Bagel	2	4	1-8	2	1-6	Runs 4 elements