



3 LEVEL PASTRY CASE

Includes Case and Set of 13" x 18" Trays.
Available Only in Black.

ITEM PC300-13 | 16Wx20Dx24H

ITEM GL1620-C | Replacement Tray



IRON STRAIGHT FRONT DISPLAY CASE

Straight Front for Self or Attendant Serve.
Includes 3 Clear Trays.

ITEM 1735-1318 | 19Wx15Dx21½H

REPLACEMENT TRAYS

ITEM 325-13-12 | 13x18 Replacement Tray



IRON 3 LEVEL DISPLAYS

Covers Do Not Work on These Units.
Frame Only, Plates Not Included.

ITEM 977-8-13 | 8¾Wx8¾Dx18H3 | Black

ITEM 977-10-13 | 11¾Wx11¾Dx20H | Black

ITEM 977-10-49 | 11¾Wx11¾Dx20H | Chrome



IRON CURVED FRONT DISPLAY CASE

Curved Front with 3 Doors. Self Serve.
Includes 3 Clear Trays.

ITEM 1708-1014 | 16Wx15Dx17¼H - 10x14 Tray

ITEM 1708-1318 | 18Wx16Dx21H - 13x18 Tray

REPLACEMENT TRAYS

ITEM 335-10-12 | 10x14 Replacement Tray

ITEM 325-13-12 | 13x18 Replacement Tray



IRON DISPLAY CASE

Includes 3 - 10" x 14" Clear Trays.

ITEM 22710-13 | 13¾WX16DX16½H

ITEM 335-10-12 | REPLACEMENT TRAY



IRON BAKERY STAND

Covers Do Not Work on These Units.
Frame Only, Trays Not Included.

ITEM 23402-49 | 18Wx10½Dx20¾H

ITEM 335-10-12 | Optional Clear Tray



WIRE BREAD BASKET

ITEM 22009-13 | 6½DIAx3½H



IRON SQUARE WIRE BASKET

ITEM 1293TRAY | 12Wx12DX3H



IRON RECTANGULAR WIRE BASKET

ITEM 1291TRAY | 18Wx12DX3H