

MODEL H TENDERIZER PARTS MANUAL

PART NUMBER	DESCRIPTION
1H	Base
2-44-17-43-55HN	Boat
3-AHN	S/S Stripper Frame Bar
3-HN	S/S Stripper Frame
3-13-15H	S/S Stripper Frame Assembly Complete
4-71R	S/S Handle
8H	Coupling Bar
9-51-31-32-56H	Column Complete
10HA	S/S jamming Cross Bar
11H	Removable Dove Tail Bar
11AE	Knurled Nuts
12H	Jamming Ring
13-HN	Stripper Frame Column
15S/SE	Stripper Frame Peg Bolt
16	Individual Blade
16A-34H	Complete Blade Set
18H	Bushing for 70S-H Connecting Rod Secondary
19AH	Bolt
20AH	Nut
21-22AE	Adjustable Screw Nut Assembly
22HN	Hold Down Plate

MODEL H TENDERIZER PARTS MANUAL

PART NUMBER	DESCRIPTION
23N	Jamming Ring Bolt
25E	Jamming Ring Stop Screw
25H	Board
26-27-28-29-30H	Telescopic Tube Assembly
26AE	Boat Bushing (small)
27AE	Boat Bushing (large)
31AH	14mm Lower Column Bolt
32AH	12mm Upper Column Bolt
33AE-S/S	Blade Separator Washer
33H	Bolt
34AE	Blade End Screw
34H	Nut
35AE	Blade End Washer
39-40H	Stop Screw & Jam Nut
40AE	S/S Board Guard
40E-S	S/S Board Handle
41AE	Channeled Separator
42H	Blade Central Rod
43H	Boat Frame Peg Bolt (15AS/SE)
51H	Washer
56H	Washer

MODEL H TENDERIZER PARTS MANUAL

PART NUMBER	DESCRIPTION
58-59H	"T" Safety Locker
65H-C Right	Channeled Separator Holder
65H-C Left	Channeled Separator Holder
70S-H	Connecting Rod Secondary