

# Café Tables



**MICROMESH TOPS**  
 2202430-01 • 24" x 30" Rectangle  
 2203030-01 • 30" x 30" Square  
 2203000-01 • 30" Round



**SOLID METAL TOPS**  
 2212430-01 • 24" x 30" Rectangle  
 2213030-01 • 30" x 30" Square  
 2213000-01 • 30" Round



**WERZALIT® SOLID TOPS**  
 2313000-01 • 30" Round  
 2313232-01 • 32" x 32" Square Top



**ACRYLIC SOLID TOPS**  
 2413000-01 • 30" round  
 2413030-01 • 30" x 30"



2342700-01  
 Butterfly Café Base  
 ~ BASE ONLY ~  
 29H x 28 diagonal  
 leg spread



2345700-01  
 Bar Table Base  
 ~ BASE ONLY ~  
 39H x 28 diagonal  
 leg spread



2332700-01  
 Spun Café Base  
 ~ BASE ONLY ~  
 29H x 24 diameter base



2335700-01  
 Spun Café Bar Base  
 ~ BASE ONLY ~  
 40H x 24 diameter base

Note: All table tops come with umbrella hole EXCEPT the 24" x 30" size

# Dining Tables



**MICROMESH TOPS**  
 2203636-01 • 36" x 36" Square  
 2203600-01 • 36" Round  
 2204200-01 • 42" Round

42" Round tops are not recommended for use with bar table bases.



**SOLID METAL TOPS**  
 2213636-01 • 36" x 36" Square  
 2213600-01 • 36" Round



**WERZALIT® SOLID TOPS**  
 2313636-01 • 36" x 36" Square  
 2313600-01 • 36" Round  
 2313248-01 • 32" x 48" Rectangle  
 (to be used with 2353048)



**ACRYLIC SOLID TOPS**  
 2413600-01 • 36" round  
 2413636-01 • 36" x 36"  
 2413048-01 • 30" x 48"



2343700-01  
 Butterfly Dining Base  
 ~ BASE ONLY ~  
 29H x 32 diagonal leg spread



2333700-01  
 Spun Dining Base  
 ~ BASE ONLY ~  
 29H x 28 diameter base



2334700-01  
 Spun Bar Base  
 ~ BASE ONLY ~  
 40H x 28 diameter base



2344700-01  
 Bar Table Base  
 ~ BASE ONLY ~  
 39H x 32 diagonal  
 leg spread



2353048-01  
 Dining T-base for 32x48 top  
 ~ BASE ONLY ~  
 29H x 32 leg spread

Note: All table tops come with umbrella hole EXCEPT the 24" x 30" size