

LIZBON



LIZ01KF00
Stack Espresso Cup
3 oz.
12/cs



LIZ01CF00
Stack Coffee Cup
8 oz.
12/cs



LIZ01MG00
Stack Mug
10 oz.
12/cs




LIZ01SU00
Creamer
3.5 oz.
6/cs




LIZ12JK00
Stack Bowl
4.75", 14 oz.
12/cs



LIZ10JK00
Stack Cup Bouillon
/ Sugar
4", 8 oz.
24/cs



LIZ01KT00
Saucer
Espresso Cup
4.5"
12/cs



LIZ01CT00
Saucer Coffee Cup
6"
12/cs




LIZ01TZ00
Salt Shaker
2" D X 3" H
24/cs




LIZ18KT00
Saucer Stack Bowl
/ sugar bowl
7"
12/cs



LIZ06JK00
Stack Ramekin
2.25", 1.75 oz.
24/cs



LIZ01BR00
Pepper Shaker
2" D x 3" H
24/cs




LIZ08JK00
Stack Ramekin
3", 3.75 oz.
24/cs



LIZ16DU00
Plate
6.25"
12/cs



LIZ24DU00
Plate
9.25"
12/cs



LIZ23CK00
Rim Soup Bowl
9" 9 oz.
12/cs



LIZ15KK00
Bowl
5.75" x 5.75" x 1.5"
12 oz.
12/cs



LIZ24KY00
Oval Platter
9.5" x 6.75" x 1"
6/cs

LIZ18DU00
Plate
7"
12/cs

LIZ27DU00
Plate
10.5"
12/cs

LIZ30CK00
Deep Pasta/Salad
Plate
11.75", 24 oz.
6/cs

LIZ19KK00
Bowl
7.25" x 7.25" x 2.25"
24 oz.
12/cs

LIZ29KY00
Oval Platter
11.25" x 8" x 1"
6/cs

LIZ20DU00
Plate
7.75"
12/cs

LIZ30DU00
Plate
11.75"
6/cs

LIZ23KK00
Bowl
9" x 9" x 2.75"
42 oz.
6/cs

LIZ34KY00
Oval Platter
13.25" x 9.25" x 1.25"
6/cs

LIZ22DU00
Plate
8.5"
12/cs

LIZ32DU00
Plate
12.25"
6/cs

LIZ39KY00
Oval Platter
15.25" x 10.5" x 1.5"
6/cs