



PB21FP

WOOD PELLET FIRE PIT

IMPORTANT, READ CAREFULLY, RETAIN
FOR FUTURE REFERENCE. MANUAL MUST
BE READ BEFORE OPERATING!

FOYER À GRANULÉS DE BOIS

IMPORTANT, PRENEZ CONNAISSANCE DE
CE DOCUMENT ET CONSERVEZ-LE POUR
RÉFÉRENCE ULTÉRIEURE VOUS DEVEZ LIRE
CE GUIDE AVANT D'UTILISER LE FOYER!

POZO DE FUEGO PARA PELLETS DE MADERA

IMPORTANTE, LEER DETENIDAMENTE,
CONSERVAR PARA REFERENCIA FUTURA.
LEA EL MANUAL ANTES DEL USO!

MODEL / MODÈLE / MODELO : PB21FP
PART / PIÈCE / PARTE : 10842, 10889

FOR OUTDOOR AND HOUSEHOLD USE ONLY.
NOT FOR COMMERCIAL USE. FUEL NOT INCLUDED.

RÉSERVÉ À L'USAGE EXTÉRIEUR ET RÉSIDENTIEL UNIQUEMENT. NON
DESTINÉ À UN USAGE COMMERCIAL. CARBURANT NON INCLUS.

SOLO PARA USO DOMÉSTICO Y EN EL EXTERIOR. NO APTO PARA USO
COMERCIAL. COMBUSTIBLE NO INCLUIDO.



ASSEMBLY AND OPERATION ASSEMBLAGE ET FONCTIONNEMENT | MONTAJE Y OPERACIÓN

WARNING: PLEASE READ THE ENTIRE MANUAL BEFORE INSTALLATION AND USE. FAILURE TO FOLLOW THESE INSTRUCTIONS COULD RESULT IN PROPERTY DAMAGE, BODILY INJURY, OR EVEN DEATH. CONTACT LOCAL BUILDING OR FIRE OFFICIALS ABOUT RESTRICTIONS AND INSTALLATION INSPECTION REQUIREMENTS IN YOUR AREA.

AVERTISSEMENT: VEUILLEZ LIRE L'INTÉGRALITÉ DU MANUEL AVANT L'INSTALLATION ET L'UTILISATION. LE NON-RESPECT DE CES INSTRUCTIONS PEUT ENTRAINER DES DOMMAGES AUX BIENS, DES BLESSURES OU MÊME LA MORT. COMMUNIQUEZ AVEC LES AUTORITÉS LOCALES EN MATIÈRE D'INCENDIE ET DE BÂTIMENT CONCERNANT LES RESTRICTIONS ET LES EXIGENCES D'INSTALLATION DANS VOTRE RÉGION.

ADVERTENCIA: LEA EL MANUAL COMPLETO ANTES DE INSTALAR Y UTILIZAR. INCUMPLIR ESTAS INSTRUCCIONES PODRÍA CAUSAR DAÑOS MATERIALES, LESIONES CORPORALES, E INCLUSO LA MUERTE. CONSULTE A SUS FUNCIONARIOS LOCALES DE CONSTRUCCIÓN Y CONTROL DE INCENDIOS PARA INFORMARSE SOBRE LAS RESTRICCIONES Y LOS REQUISITOS DE INSPECCIÓN DE INSTALACIONES EN SU REGIÓN.

SAFETY INFORMATION

MAJOR CAUSES OF UNCONTROLLED FIRES ARE A RESULT OF POOR CARE AND A FAILURE TO MAINTAIN REQUIRED CLEARANCE TO COMBUSTIBLE MATERIALS. IT IS OF UTMOST IMPORTANCE THAT THIS PRODUCT BE USED ONLY IN ACCORDANCE WITH THE FOLLOWING INSTRUCTIONS.

Please read and understand this entire manual before attempting to assemble and operate the product. This will ensure you receive the most enjoyable and trouble-free use of your new Fire Pit. We also advise you retain this manual for future reference.

DANGERS AND WARNINGS

You must contact your local home association, building or fire officials, or authority having jurisdiction, to obtain the necessary permits, permission, or information on any installation restrictions, such as any Fire Pit being installed on a combustible surface, inspection requirements, or even ability to use, in your area.

1. A minimum clearance of 2.4 m (96 inches) from combustible constructions to all sides of the Fire Pit to combustible constructions must be maintained. **Do not position on combustible floors, or floors protected with combustible surfaces unless proper permits and permissions are obtained by authorities having jurisdiction.** Do not use in vehicles, tents, indoors, or in an enclosed, unventilated area. Do not place under overhead combustible ceiling, overhang, or canopy of trees. Keep your Fire Pit in an area clear and free from combustible materials, gasoline, and other flammable vapors or liquids.

Do not leave fire unattended. Use of an all-class (class ABC) approved fire extinguisher is valuable to keep on site. If an uncontrolled fire does occur, call the Fire Department.

2. This Fire Pit is designed for burning hardwood pellets, firewood logs, or wood chunks only.

Do not use charcoal, spirit, petrol, gasoline, or kerosene for lighting or refreshing a fire in your Fire Pit. Keep all such liquids well away from the appliance when in use.

3. Ensure that the Wind Break is secured over the Burner while in use. During use, this unit can reach extreme temperatures that can cause serious injury. It is recommended to use a poker, heat-resistant barbecue mitts, or gloves when using the Fire Pit. Do not use accessories not specified for use with this unit. Do not put a cover or anything flammable on the unit while in use. Ensure the Fire Pit have cooled before placing a cover overtop.

4. Do not transport your Fire Pit while in use or while the Fire Pit is hot. Ensure the fire is completely out and that the Fire Pit is completely cool to the touch before moving.
5. Parts of the Fire Pit may be very hot and serious injury may occur. Do not touch surface while in use. Keep young children and pets away while in use.

This unit is not recommended for children, persons with reduced physical, sensory, mental capabilities, or lack of experience and knowledge, unless they are under direct supervision or instruction by a person responsible for their safety.

6. Do not enlarge, modify, or alter this product. Failure to follow this warning could lead to a fire hazard and/or bodily harm, and will void your warranty.
7. After a period of storage, or non-use, check the interior of the Burner for foreign objects, and any air blockage around the intake holes. Regular care and maintenance is required to prolong the lifespan of your unit. If the Fire Pit is stored outside during the rainy season or seasons of high humidity, hardwood pellets will expand greatly, decompose, and may jam the airflow system.

HARDWOOD PELLET FUEL

This appliance is designed and approved for wood fuel only. Any other type of fuel burned in this appliance will void the warranty and safety listing. Do not use fuel with additives. Hardwood pellets are highly susceptible to moisture and should always be stored in an airtight container. If you are storing your Fire Pit, without use, for an extended period, we recommend clearing all ash and remaining fuel from the ash pan to avoid air blockage. The pellet fuel mean heating value in 8000-8770 BTU/LB, ash content < 1%.

Do not use spirit, petrol, gasoline, lighter-fluid, or kerosene for lighting or refreshing a fire in your Fire Pit. Keep all such liquids well away from the appliance when in use.

At time of printing, there is no industry standard for barbecue hardwood pellets, although most pellet mills use the same standards to make hardwood pellets for domestic use. Further information can be found at www.pelletheat.org or the Pellet Fuel Institute. Contact your local dealer on the quality of pellets in your area and for information on brand quality. As there is no control over the quality of pellets used, we assume no responsibility to damage caused by poor quality of fuel.

DISPOSAL OF ASHES

Ashes should be placed in a metal container with a tight-fitting lid. The closed container of ashes should be placed on a non-combustible floor or on the ground, well away from all combustible materials, pending final disposal. When ashes are disposed by burial in soil, or otherwise locally dispersed, they should be retained in a closed container until all cinders have thoroughly cooled.

CARBON MONOXIDE ("THE SILENT KILLER")

Carbon monoxide is a colorless, odorless, tasteless gas produced by burning gas, wood, propane, charcoal, or other fuel. Carbon monoxide reduces the blood's ability to carry oxygen. Low blood oxygen levels can result in headaches, dizziness, weakness, nausea, vomiting, sleepiness, confusion, loss of consciousness, or death. Follow these guidelines to prevent this colorless, odorless gas from poisoning you, your family, or others:

- See a doctor if you or others develop cold or flu-like symptoms while cooking or in the vicinity of the unit. Carbon monoxide poisoning, which can easily be mistaken for a cold or flu, is often detected too late.
- Alcohol consumption and drug use increase the effects of carbon monoxide poisoning.

Carbon monoxide is especially toxic to mother and child during pregnancy, infants, the elderly, smokers, and people with blood or circulatory system problems, such as anemia, or heart disease.



COPYRIGHT NOTICE

Copyright 2023. All right reserved. No part of this manual may be copied, transmitted, transcribed, stored in a retrieval system, in any form or by any means without expressed written permission of,

Dansons

8877 North Gainey Center Drive, Scottsdale, AZ, USA 85258
www.pitboss-grills.com

Customer Care

USA: (480) 923-9630
Canada (Toll-Free): 1-877-942-2246


TABLE OF CONTENTS

Safety Information	2
Parts & Specs.....	5
Assembly Preparation.....	6
Assembly Instructions	6
Instructions For Use	
Lighting Instructions	7
Tending The Fire.....	7
Extinguishing The Fire	7
Travel And Storage	7
Care & Maintenance	8
Replacement Parts.....	9
Warranty.....	10

PARTS & SPECS

Part#	Description
1	Wind Break (x1)
2	Burner (x1)

NOTE: Due to ongoing product development, parts are subject to change without notice. Contact Customer Care if parts are missing when assembling the unit.



MODEL		ASSEMBLED (WxDxH)	WEIGHT
PB	PB21FP	578.8 MM X 578.8 MM X 464 MM / 22.7 IN. X 22.7 IN. X 18.3 IN.	15.6 KG / 34.39 LB

ASSEMBLY PREPARATION


Parts are located throughout the shipping carton, including inside the Burner. Unpack the unit and parts by removing all packaging materials. Before assembly, review all parts and reference the parts list. If any part is missing or damaged, do not attempt to assemble. Shipping damage is not covered under warranty. Contact your dealer or Pit Boss® Customer Care for parts.

www.pitboss-grills.com

USA: (480) 923-9630 | Canada: 1-877-942-2246

Tool required for assembly: none.

ASSEMBLY INSTRUCTIONS



INSTRUCTIONS FOR USE

LIGHTING INSTRUCTIONS

1. Start by filling the Burner of your Fire Pit with hardwood pellets. Wood chips, wood chunk, or firewood logs can also be used, but best results are using hardwood pellets.

WARNING: Do not fill past the fill-line indicator holes, as this will block airflow for the secondary burn (flame).

2. Insert lighter gel, liquid fire starter, or apply lighter-fluid to multiple areas of the fuel.
3. Use either a long handled lighter or match to light firestarter in several locations.

WARNING: Do not use charcoal, spirit, petrol, gasoline, or kerosene for lighting your Fire Pit. This could cause serious injury.

4. Fire will quickly build in the Burner, ready for enjoyment.

TENDING THE FIRE

Should the fire begin to diminish, or to extend your burn time, periodically add more fuel into the Burner while the fire is still burning. Add a small handful of fuel can be added to one side of the Burner. If using hardwood pellets as fuel, add small quantities at a time. Excessive amounts of hardwood pellets added at one time could lead to smothering of fire and excessive smoke.

CAUTION: During use, this unit can reach extreme temperatures that can cause serious injury. It is recommended to use a heat-resistant barbecue mitts or gloves when adding fuel to avoid injury.

EXTINGUISHING THE FIRE

To extinguish the fire, allow all fuel to burn out.

CAUTION: Do not use water to put out the Fire Pit. This can be harmful to the structure of the Fire Pit and heavily decrease its lifetime.

TRAVEL AND STORAGE

The Fire Pit can quickly and easily be relocated for enjoyment or travel.

IMPORTANT: Always ensure the Fire Pit is completely cooled before moving. Ensure the ash in the bottom of the unit is also removed.

1. Lift the Wind Break and flip upside-down. Replace onto top of unit.
2. Using two people, carefully lift the Fire Pit and move to desired location.

CARE & MAINTENANCE

Any Pit Boss® unit will give you many years of use with minimum cleaning. Follow these cleaning and maintenance tips to service your Fire Pit and extend its lifetime:

1. *BURNER COMPONENTS*

- It is recommended to empty the Burner and Ash Pan after every few uses. This will avoid any hard build-up of debris or ash in the bottom. When cool and all fuel has burned completely, lift the Burner Shell off the Ash Pan to dispose of ashes.
- With regular use, the bottom of the Burner may discolor. This is a normal occurrence and should not be considered a defect of the product.

2. *EXTERIOR*

- Wipe the Burner Shell and Wind Break down as needed. Ensure the Fire Pit is completely cool prior to cleaning.
- A cover is your best protection against weather and outside pollutants. When not in use or for longterm storage, keep the unit under a cover in a garage or shed.


CLEANING TIME TABLE (NORMAL USE)

ITEM	CLEANING FREQUENCY	CLEANING METHOD
Burner Shell, Wind Break	As Needed	Cloth & Soapy Water
Burner	Every 2-3 Burns	Scoop Out, Wet/dry Vacuum Excess Debris
Ash Pan	Every 2-3 Burns	Scoop Out, Wet/dry Vacuum Excess Debris

REPLACEMENT PARTS

Part#	Description
1	Wind Break (x1)
2	Burner (x1)
3	Burner Shell (x1)
4	Logo Plate (x1)
5	Ash Pan (x1)
6	Foot Mats (x4)

NOTE: Due to ongoing product development, parts are subject to change without notice.



WARRANTY

CONDITIONS

All Fire Pits by Pit Boss®, manufactured by Dansons, carry a limited warranty from the date of sale by the original owner. The warranty coverage begins on the original date of purchase and proof of date of purchase, or copy of original bill of sale, is required to validate the warranty. Customers will be subject to parts, shipping, and handling fees if unable to provide proof of the purchase or after the warranty has expired. Dansons carries a one (1) year warranty against defects and workmanship on all parts. Dansons warrants that all part(s) are free of defects in material and workmanship, for the length of use and ownership of the original purchaser. Warranty does not cover damage from wear and tear, such as scratches, dents, dings, chips, or minor cosmetic cracks. These aesthetic changes of the Fire Pit do not affect its performance. Repair or replacement of any part does not extend past the limited warranty beyond the one (1) year from date of purchase.

During the term of the warranty, Dansons obligation shall be limited to furnishing a replacement for defective and/or failed components. As long as it is within the warranty period, Dansons will not charge for repair or replacement for parts returned, freight prepaid, if the part(s) are found by Dansons to be defective upon examination. Dansons shall not be liable for transportation charges, labor costs, or export duties. Except as provided in these conditions of warranty, repair, or replacement of parts in the manner and for the period of time mentioned heretofore shall constitute the fulfillment of all direct and derivate liabilities and obligations from Dansons to you.

Dansons takes every precaution to utilize materials that resist rust. Even with these safeguards, the protective coatings can be compromised by various substances and conditions beyond Dansons control. High temperatures, excessive humidity, chlorine, industrial fumes, fertilizers, lawn pesticides, and salt are some of the substances that can affect metal coatings. For these reasons, the warranty does not cover rust or oxidization, unless there is loss of structural integrity on the Fire Pit components. Should any of the above occur, kindly refer to the care and maintenance section to maintain the finish of your Fire Pit and prolong its lifespan. Dansons recommends the use of a full length protective cover when the Fire Pit is not in use. This warranty is based on normal domestic use and service of the Fire Pit and neither limited warranty coverage's apply for a Fire Pit which is used in commercial applications.

EXCEPTIONS

There is no written or implied performance warranty on Pit Boss®, as the manufacturer has no control over the installation, operation, cleaning, maintenance, or the type of fuel burned. This warranty will not apply nor will Dansons assume responsibility if your appliance has not been installed, operated, cleaned, and maintained in strict accordance with this owner's manual. Any use of fuel not outlined in this manual may void the warranty. The warranty does not cover damage or breakage due to misuse, improper handling, or modifications.

Neither Dansons, or authorized Pit Boss® dealer, accepts responsibility, legal or otherwise, for the incidental or consequential damage to the property or persons resulting from the use of this product. Whether a claim is made against Dansons based on the breach of this warranty or any other type of warranty expressed or implied by law, the manufacturer shall in no event be liable for any special, indirect, consequential, or other damages of any nature whatsoever in excess of the original purchase of this product. All warranties by manufacturer are set forth herein and no claim shall be made against manufacturer on any warranty or representation.

Some states do not allow the exclusion or limitation of incidental or consequential damages, or limitations of implied warranties, so the limitations or exclusions set forth in this limited warranty may not apply to you. This limited warranty gives you specific legal rights and you may have other rights, which vary from state to state.

ORDERING REPLACEMENT PARTS

To order replacement parts, please contact your local Pit Boss® Grills dealer or visit our online store at:
www.pitboss-grills.com

CUSTOMER CARE

If you have any questions or problems, contact Customer Care.
www.pitboss-grills.com
USA: (480) 923-9630 | Canada: 1-877-942-2246

PROCEDURE FOR WARRANTY SERVICE

Contact your nearest Pit Boss® dealer for repair or replacement parts. Danson's requires proof of purchase to establish a warranty claim; therefore, retain your original sales receipt or invoice for future reference. Record data in the space below as the safety rating label may become worn or illegible.

MODEL	SERIAL NUMBER
DATE OF PURCHASE	AUTHORIZED DEALER