



Flat plate

Assiette plate
Teller flach
Plato llano
Piatto piano

LRFP31 31 cm / 12.20"



LRFP29 29 cm / 11.40"

LRFP27 27 cm / 10.65"

LRFP24 24 cm / 9.45"

LRFP21 21 cm / 8.25"



LRFP17 17 cm / 6.70"

LRFP15 15 cm / 5.90"



Oval platter

Plat ovale
Platte oval
Fuente oval
Piatto ovale

LROP38 38 x 27 cm
14.95 x 10.65"

LROP32 32 x 22.5 cm
12.60" x 8.85"



Stackable salad bowl

Saladier empilable
Salatschale stapelbar
Ensaladera apilable
Insalatiera impilabile

LRSB18 18 cm - 29 cl
7.10" - 9.80 oz

LRSB12 12 cm - 15 cl
4.70" - 5.05 oz



Deep plate

Assiette creuse
Teller tief
Plato hondo
Piatto fondo

LRDP30 30 cm / 11.80"



LRDP26 26 cm / 10.25"

LRDP23 23 cm / 9.05"



Stackable soup bowl

Tasse à bouillon empilable
Suppentasse stapelbar
Bol consommé apilable
Scodella per zuppa impilabile

LRCS30 10.5 cm - 6 cm - 30 cl
4.15" - 2.35" - 10.15 oz



Tajine cover

for deep plate
Couvercle tajine
pour assiette creuse
Tajine Deckel
für tiefe Teller
Tapa tajine
para plato hondo
Coperchio tajine
per piatto fondo

LRCV27 > LRDP30

LRCV23 > LRDP26



Saucer

Soucoupe
Untere
Platillo
Piattino

LRSA17 > LRCS30
17 cm / 6.70"





Non stackable cup
Tasse non empilabile
Tasse nicht stapelbar
Taza no apilable
Tazza non impilabile

LRCU27 27 cl / 9.15 oz

LRCU22 22 cl / 7.45 oz

LRCU18 18 cl / 6.10 oz



Stackable cup
Tasse empilabile
Tasse stapelbar
Taza apilable
Tazza non impilabile

LRSC27 27 cl / 9.15 oz

LRSC22 22 cl / 7.45 oz

LRSC18 18 cl / 6.10 oz



Saucer
Soucoupe
Untere
Platillo
Piattino

LRSA17 > LRCU27 / LRSC27

17 cm / 6.70"

**LRSA15 > LRCU22 / LRCU18 /
LRSC22 / LRSC18**

15 cm / 5.90"



Non stackable cup
Tasse non empilabile
Tasse nicht stapelbar
Taza no apilable
Tazza non impilabile

LRCU09 9 cl / 3.05 oz



Stackable cup
Tasse empilabile
Tasse stapelbar
Taza apilable
Tazza non impilabile

LRSC09 9 cl / 3.05 oz



Saucer
Soucoupe
Untere
Platillo
Piattino

LRSA12 > LRCU09 / LRSC09

12 cm / 4.70"

