

BANQUET



Coffee pot & lid
Cafetière & couvercle
Cafetera & tapa

BACP70 70 cl / 23.65 oz

BACP35 35 cl / 11.85 oz



Lid for coffee pot
Couvercle pour cafetière
Tapa para cafetera

BACPLD2 > BACP70

BACPLD1 > BACP35



Gravy boat

Saucière

Salsera

BAGB35 35 cl / 11.85 oz



BAGB15 15 cl / 5.05 oz



Saucer

Soucoupe

Platillo

BASA15 > BAGB35

15 cm / 5.90"

BASA13 > BAGB15

13 cm / 5.10"



Teapot & lid
Théière & couvercle
Tetera & tapa

BATP100 100 cl / 33.80 oz



BATP80 80 cl / 27.05 oz



BATP40 40 cl / 13.55 oz



Lid for teapot
Couvercle pour théière
Tapa para tetera

BATPLD2 > BATP80



BATPLD1 > BATP40



Stackable butter ramekin

Ramequin beurre empilable

Platillo para mantequilla apilable

BABR02 8 cm - 3.5 cm - 10 cl

3.15" - 1.40" - 3.40 oz



Stackable butter ramekin

Ramequin beurre empilable

Platillo para mantequilla apilable

BABR03 7 cm - 3 cm - 6 cl

2.75" - 1.20" - 2.05 oz



Creamer

Crémier

Lechera

BACR35 35 cl / 11.85 oz

BACR25 25 cl / 8.45 oz

BACR15 15 cl / 5.05 oz



BACR05 50 cl / 16.90 oz



Butter ramekin

Ramequin beurre

Platillo para mantequilla

BABR01 6.7 cm - 6 cl / 2.65" - 2.05 oz

BABR05 5 cm / 1.95"

