



Breakfast cup
Tasse à déjeuner
Taza a desayuno

GICU39 11.5 cm - 39 cl
4.55" - 13.20 oz



Coffee cup
Tasse à café
Taza a café

GICU20 8 cm - 20 cl
3.15" - 6.75 oz

GICU15 7.2 cm - 15 cl
2.85" - 5.05 oz



Chocolate cup
Tasse à chocolat
Taza a chocolate

GICU29 9.3 cm - 29 cl
3.65" - 9.80 oz



Espresso cup
Tasse à espresso
Taza a expreso

GICU09 6 cm - 9 cl
2.35" - 3.05 oz



Coffee cup
Tasse à café
Taza a café

GICU23 8.3 cm - 23 cl
3.25" - 7.80 oz



Saucer
Soucoupe
Platillo

**GISA14 > GICU20 / GICU15 /
GICU09**

14.5 cm / 5.70"



Saucer
Soucoupe
Platillo

GISA17 > GICU39 / GICU29 / GICU23
17 cm / 6.70"



Oval saucer
Soucoupe ovale
Platillo oval

**GISA29 > GICU29 / GICU23 /
GICU15 / GICU09**

29 x 16 cm / 11. x 6.30"

