

**Bowl**

Bol

Bol

BABW14D7 14.1 cm - 6.3 cm - 63 cl
5.55" - 2.50" - 21.30 oz

BABW12D7 12.2 cm - 6.4 cm - 48 cl
4.80" - 2.50" - 16.25 oz

12

**Stackable cup**

Tasse empilable

Taza apilable

BACU23D7 23 cl / 7.80 oz

BACU20D7 20 cl / 6.75 oz

BACU18D7 18 cl / 6.10 oz

12

**Saucer**

Soucoupe

Platillo

**BASA15D7 > BACU23D7 / BACU20D7
BACU18D7**

15 cm / 5.90"

12

**Stackable cup**

Tasse empilable

Taza apilable

BACU09D7 9 cl / 3.05 oz

12

**Saucer**

Soucoupe

Platillo

BASA13D7 > BACU09D7

13 cm / 5.10"

12

**Coffee pot & lid**

Cafetière & couvercle

Cafetera & tapa

BACP70D7 70 cl / 23.65 oz

BACP35D7 35 cl / 11.85 oz

4

Lid for coffee pot

Couvercle pour cafetière

Tapa para cafetera

BACPLD2D7 > BACP70D7

BACPLD1D7 > BACP35D7

12

**Teapot & lid**

Théière & couvercle

Tetera & tapa

BATP80D7 80 cl / 27.05 oz

BATP40D7 40 cl / 13.55 oz

4

Lid for teapot

Couvercle pour théière

Tapa para tetera

BATPLD2D7 > BATP80D7

BATPLD1D7 > BATP40D7

12