

**Bowl**

Bol
Schale
Bol
Coppetta

HMPASBW21 21 cm - 130 cl
8.25" - 43.95 oz



HMPASBW18 18 cm - 75 cl
7.10" - 25.35 oz

HMPASBW16 16 cm - 60 cl
6.30" - 20.30 oz

HMPASBW12 12 cm - 33 cl
4.70" - 11.15 oz

**Bouillon cup - 2 handles**

Tasse à bouillon - 2 anses
Suppentasse - 2 Henkel
Bol consommé - 2 asas
Scodella per zuppa - 2 manici

HMPASCS30 30 cl / 10.15 oz

**Stackable bouillon cup without handle**

Tasse à bouillon empilable sans anse
Suppentasse stapelbar ohne Henkel
Bol consommé apilable sin asas
Scodella per zuppa impilabile senza manici

HMPASCS02M 30 cl / 10.15 oz

**Saucer**

Soucoupe
Untere
Platillo
Piatino

HMPASSA17 > HMPASCS02 / HMPASCS02M

17 cm / 6.70"



HMPASSA15 > HMPASCS30 / HMPASCS01

15 cm / 5.90"

**Bouillon cup without handle**

Tasse à bouillon sans anse
Suppentasse ohne Henkel
Bol consommé sin asas
Scodella per zuppa senza manici

HMPASCS01 30 cl / 10.15 oz

**Cereal bowl**

Bol à céréales
Muesli-Schale
Tazon de cereales
Coppetta per cereali

HMPASCB16 16 cm / 6.30"

**Stackable bouillon cup - 2 handles**

Tasse à bouillon empilable - 2 anses
Suppentasse stapelbar - 2 Henkel
Bol consommé apilable - 2 asas
Scodella per zuppa impilabile - 2 manici

HMPASCS02 30 cl / 10.15 oz

**Breakfast cup**

Tasse à déjeuner
Frühstückstasse
Taza a desayuno
Tazza da colazione

HMPASMG45 45 cl / 15.20 oz

HMPASCU30 30 cl / 10.15 oz

