

PIXEL



Flat plate

Assiette plate

Plato llano

PXFP32 32 cm / 12.60"



PXFP29 29 cm / 11.40"

PXFP27 27 cm / 10.65"

PXFP24 24 cm / 9.45"

PXFP21 21 cm / 8.25"



PXFP17 17 cm / 6.70"



Cream soup bowl, 2 handles

Tasse à bouillon, 2 anses

Bol consomé, 2 asas

PXCS35 11.4 cm - 6.6 cm - 35 cl

4.50" - 2.60" - 11.85 oz



Cream soup bowl

Tasse à bouillon

Bol consomé

PXCS01 11.6 cm - 6.5 cm - 35 cl

4.55" - 2.55" - 11.85 oz



Deep plate

Assiette creuse

Plato hondo

PXDP28 28 cm / 11"

PXDP24 24 cm / 9.45"



Cup

Tasse

Taza

PXCU35 35 cl / 11.85 oz

PXCU30 30 cl / 10.15 oz

PXCU27 27 cl / 9.15 oz



Oval plate

Plat ovale

Fuente oval

PXOP36 36 cm / 14.15"

PXOP34 34 cm / 13.40"



Saucer

Soucoupe

Platillo

PXSA17 > **PXCU35** / **PXCU30** / **PXCU27** /

PXCS01 / **PXCS35**

17 cm / 6.70"



Cereal bowl

Bol à céréales

Bol a cereales

PXBC30 13.5 cm - 5.5 cm - 30 cl

5.30" - 2.15" - 10.15 oz



Pieces per box

Pièces par boîte

Piezas por caja