

EDGE




Espresso cup
Tasse à expresso
Espressotasse
Taza a expreso
Tazza da espresso

EDCU09 9 cl / 3.05 oz



Coffee pot & lid
Cafetière & couvercle
Kaffeekanne & Deckel
Cafetera & tapa
Caffettiera & coperchio

EDCP35 35 cl / 11.85 oz



Saucer
Soucoupe
Untere
Platillo
Piattino

EDSA13 > EDCU09
13 cm / 5.10"



Teapot & lid
Théière & couvercle
Teekanne & Deckel
Tetera & tapa
Teiera & coperchio

EDTP40 40 cl / 13.55 oz



Mug
Chope
Becher
Mug
Mug

EDMU30 30 cl / 10.15 oz



Creamer
Crémier
Milchkännchen
Lechera
Bricco da latte

EDCR25 25 cl / 8.45 oz

EDCR15 15 cl / 5.05 oz



Saucer
Soucoupe
Untere
Platillo
Piattino

EDSA17 > EDMU30
17 cm / 6.70"



Pieces per box
Pièces par boîte
Stück pro Karton
Piezas por caja
Pezzi per scatola