

**Stackable coffee cup**

Tasse à café empilable
Kaffeetasse stapelbar
Taza a café apilable
Tazza da caffè impilabile

HMPASSC20 20 cl / 6.75 oz

12

**Saucer**

Soucoupe pour
Untere für
Platillo para
Piattino per

**HMPASSA15 > HMPASSC09 / HMPASSC20 /
HMPASSC23**

15 cm / 5.90"

12

**Stackable espresso cup**

Tasse à expresso empilable
Espressotasse stapelbar
Taza a expreso apilable
Tazza da espresso impilabile

HMPASSC09 9 cl / 3.05 oz

12

**Saucer**

Soucoupe
Untere
Platillo
Piattino

HMPASSA13 > HMPASSC09

13 cm / 5.10"

12

**Stackable mug**

Chope empilable
Becher stapelbar
Mug apilable
Mug impilabile

HMPASSM36 36 cl / 12.15 oz

12

**Saucer**

Soucoupe
Untere
Platillo
Piattino

HMPASSA15 > HMPASSM36

15 cm / 5.90"

12

**Coffee pot & lid**

Cafetière & couvercle
Kaffeekanne & Deckel
Cafetera & tapa
Caffettiera & coperchio

HMPASCP70 70 cl / 23.65 oz

HMPASCP35 35 cl / 11.85 oz

4

**Teapot & lid**

Théière & couvercle
Teekanne & Deckel
Tetera & tapa
Teiera & coperchio

HMPASTP80 80 cl / 27.05 oz

HMPASTP45 45 cl / 15.20 oz

4

**Creamer**

Crémier
Milchkännchen
Lechera
Bricco da latte

HMPASCR40 40 cl / 13.55 oz

6



HMPASCR25 25 cl / 8.45 oz

HMPASCR15 15 cl / 5.05 oz

12

**Sugar bowl & lid**

Sucrier & couvercle
Zuckerdose & Deckel
Azucarero & tapa
Zuccheriera & coperchio

HMPASSU23 23 cl / 7.80 oz

12