

**Bowl**

Bol
Schale
Bol
Coppetta

ASBW21 21 cm - 130 cl
8.25" - 43.95 oz



ASBW18 18 cm - 75 cl
7.10" - 25.35 oz

ASBW16 16 cm - 60 cl
6.30" - 20.30 oz

ASBW12 12 cm - 33 cl
4.70" - 11.15 oz

**Cream soup bowl**

Tasse à bouillon
Suppentasse
Bol consommé
Scodella per zuppa

ASCS30 30 cl / 10.15 oz

**Stackable cream soup bowl**

Tasse à bouillon empilable
Suppentasse stapelbar
Bol consommé apilable
Scodella per zuppa impilabile

ASCS02 30 cl / 10.15 oz

**Cream soup bowl without handle**

Tasse à bouillon sans anses
Suppentasse ohne Henkel
Bol consommé sin asas
Scodella per zuppa senza manici

ASCS01 30 cl / 10.15 oz

**Saucer**

Soucoupe
Untere
Platillo
Piatino

ASSA17 > ASCS02

17 cm / 6.70"



ASSA15 > ASCS30 / ASCS01

15 cm / 5.90"

**Cereal bowl**

Bol à céréales
Muesli Schale
Tazón de cereales
Coppetta di cereali

ASCB16 16 cm / 6.30"

**Tea cup**

Tasse à thé
Teetasse
Taza a té
Tazza da tè

ASCU23 23 cl / 7.80 oz

